



# 60069



CA



4

DA



4

LJ



2

NB



4


VR





8

7


8



1




8




7

2



2






1


60035

3


3




|    |             |
|----|-------------|
| F  | REGLAGE     |
| GB | ADJUSTING   |
| I  | REGOLAZIONE |
| E  | AJUSTER     |
| D  | ANPASSUNG   |
| P  | REGULACAO   |
| NL | AFSTELLING  |






A



B




C



## ENTRETIEN

CLEANING  
UNTERHALTUNG  
GESPREK

ALCOOL A BRULER  
METHYLATED SPIRITS  
BRENNSPIRITUS  
BRANDSPIRITUS



CHIFFON DOUX  
SOFT RAG  
LAPPEN  
ZACHTE DOEK

I

In presenza di tracce di colla si consiglia di pulire con un panno imbevuto con alcool denaturato.

F

Pour éliminer éventuelles traces de colle sur le plateau utiliser un torchon imbibé d'alcool.